


GF72.29-P-4105PP	Front driver-side door control module, location/purpose/design/function	24.11.99
------------------	---	----------

MODEL 203

N69/1 Left front door control module



P72.29-2174-06

Driver-side front door control module, location	The left front door control module (N69/1) is located in the upper area of the left inner door.	
Driver-side front door control module, purpose		GF72.29-P-4105-03PP
Driver-side front door control module, design	Depending on the equipment version a different actuation and evaluation electronic circuitry is integrated in the door control module (N69/1) for realizing individual functions.	

Driver-side front door control module, function	The left front door control module (N69/1) is connected to the interior compartment CAN bus, it stores the current mirror position and in addition the last setting of the instrument cluster (A1).	
---	---	--