
GF54.15-P-1257-03P	Relay assignment of fuse and relay box in	⊯ GF
	engine compartment, left	

Relay assignment

N10/1 Front SAM control unit with fuse and relay module

I to S Plug positions



P54.15-2205-06

Вау	Designation	
I	Fanfare horn system relay (N10/1kl)	
K	Terminal 87 relay, chassis (N10/1kK)	
L	Wiper speed 1 and 2 relay (N10/1kL)	
М	Terminal 15R relay (N10/1kM)	
N	SEQ [ASG] pump control relay (N10/1kN) (with code (424) Sequentronic automated manual transmission (ASG))	
0	Air pump relay (N10/1kO) (engines 112, 113, 271 only)	
Р	Terminal 15 relay (N10/1kP)	
Q	Wiper ON/OFF relay (N10/1kQ)	
R	Terminal 87 relay, engine (N10/1kR)	
S	Starter relay (N10/1kS)	