

## Check component 'S62/42 (Right engine hood contact switch)'.

### Test prerequisite

- Component 'S62/42 (Right engine hood contact switch)' is installed.
- The power supply of component 'N10/1 (Front SAM control unit with fuse and relay module)' is OK.
- The associated fault codes are present or a complaint has been received.

### Status of associated error code

F	B181E2A 'The sensor for the engine hood has a malfunction. There is no signal change.'	CURRENT and STORED
---	--	--------------------

### Possible causes and remedies

- Check component 'S62/42 (Right engine hood contact switch)'.
- Check electrical line between control unit 'N10/1 (Front SAM control unit with fuse and relay module)' and component 'S62/42 (Right engine hood contact switch)'.

End of test



MB\_PKW/Steuergeraete/Grundmodule/SAM/SAM%20vorn%20-%20SAMF\_204/SAM  
F\_204.gmf#SG/Pruefungen/S62\_42/Laufzeit\_Kurzinfo/NODE2/DiagTree-Ueberschrift1