| Cover |  |  |  | Bolt tightening procedure for cylinder head cover | AR01.20-P-5014-03Q |
|-------|--|--|--|---|--------------------|
|-------|--|--|--|---|--------------------|


## $\underline{\mbox{Nm}}$ Crankcase ventilation, cylinder head cover, camshaft bearing housing

| Number             | Designation  | Engine<br>271 |
|--------------------|--|---------------|
| BA01.20-P-1001-01H | Bolt of cylinder head cover to camshaft Nm bearing housing | 9             |

## Mm ECI ignition system

| Number             | Designation                          |    | Engine<br>271 |
|--------------------|--------------------------------------|----|---------------|
| BA15.12-P-1002-01F | Ignition coil to cylinder head cover | Nm | 8             |

Tighten cylinder head cover bolts in the numerical sequence.



P01.20-2059-06