On-board computer and displays	Display messages	Possible causes/consequences and ▶ Solutions
	Stop Vehicle See Operator's Manual	The battery is no longer being charged and the condition of charge is too low. A warning tone also sounds. ► Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions. ► Secure the vehicle against rolling away (> page 158). ► Observe the instructions in the See Operator's Manual display message. ► Consult a qualified specialist workshop.
	Stop Vehicle Leave Engine Running	The battery condition of charge is too low. ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances. ▶ Leave the engine running. ▶ Wait until the display message disappears before pulling away.
	Start Engine See Operator's Manual	 The engine is switched off and the condition of charge is too low. ▶ Switch off electrical consumers that you do not need, such as the rear window defroster and interior lighting. ▶ Leave the engine running for a few minutes or drive a long distance. The battery is being charged.
	Check Engine Oil At Next Refueling	The engine oil level has dropped to the minimum level. A warning tone also sounds.
		Avoid longer journeys when there is insufficient engine oil. You could otherwise damage the engine.
		 ▶ Check the oil level when next refueling, at the latest (> page 314). ▶ If necessary, add engine oil (> page 315).
		If you have to add engine oil frequently:
		► Contact a qualified specialist workshop and have the engine checked.
		Information on approved engine oils can be obtained from a qualified specialist workshop or on the Internet at http://bevo.mercedes-benz.com.