AR07.03-P-1010-02MR	Mount high-pressure lines.		
---------------------	----------------------------	--	--

ENGINE 274

Nm Injection nozzles, injection valves, lines

Number	Designation			ENGINE 274
BA07.03-P-1001-01F	Union nut, fuel line to fuel distributor	Stage 1	Nm	15
		Stage 2	۲°	75
		Stage 3	۲°	25

Nm Injection nozzles, injection valves, lines

Number	Designation			ENGINE 274
BA07.03-P-1002-01F	Union nut, fuel line to high-pressure pump	Stage 1	Nm	15
		Stage 2	۲°	75
		Stage 3	۲°	25

Mount high pressure line (1) on high pressure pump (2) and rail (3). 1

i Lay on the union nuts for the high-pressure line (1) completely by hand.

Tighten union nuts with torque. 2

> Comply with the tightening torques exactly. Leaks can occur otherwise.

- 1
- High pressure pipe High pressure pump Rail 2 3



P07.03-2316-06