



GF54.15-P-1257-03P	Relay assignment of fuse and relay box in engine compartment, left	Model 203	 GF
--------------------	--	-----------	--

**Relay assignment**

*N10/1 Front SAM control unit with fuse and relay module  
I to S Plug positions*



P54.15-2205-06

Bay	Designation
I	Fanfare horn system relay (N10/1kI)
K	Terminal 87 relay, chassis (N10/1kK)
L	Wiper speed 1 and 2 relay (N10/1kL)
M	Terminal 15R relay (N10/1kM)
N	SEQ [ASG] pump control relay (N10/1kN) (with code (424) Sequentronic automated manual transmission (ASG))
O	Air pump relay (N10/1kO) (engines 112, 113, 271 only)

P	Terminal 15 relay (N10/1kP)
Q	Wiper ON/OFF relay (N10/1kQ)
R	Terminal 87 relay, engine (N10/1kR)
S	Starter relay (N10/1kS)