
GF54.15-P-1257-01P	Relay assignment of rear fuse and relay box		le͡GF
--------------------	---	--	-------

Assignment of fuse and relay box in rear in rear

1-20 Fuses A-H Relays N10/2 Rear SAM control module with fuse and relay module



P54.15-2206-06

Вау	Designation	
А	Fuel pump relay (N10/2kA)	
В	Relay 2, terminal 15R (N10/2kB)	
С	Reserve relay 2 (N10/2kC)	
D	Reserve relay 1 (N10/2kD)	
E	Rear window defroster relay (N10/2kE)	
F	Relay 1, terminal 15R (N10/2kF)	
G	Filler cap relay, polarity reverser 1 (N10/2kG)	
Н	Filler cap relay, polarity reverser 2 (N10/2kH)	