

## K. MOST ring configuration




Figure 45

P82.70-xxxx-11

## L. Final assembly and function test

1. In the trunk, reinstall the plastic cover over the electronics compartment at the front, passenger side paneling, and floor paneling.
  - See *WIS* document AR68.30-P-4600P, "Removing and installing paneling in trunk"
2. Reinstall the floor covering at the transmission tunnel area on the passenger side.
3. Verify proper telephone operation per the following checklist:
  - ✓ Handset dialing is functioning
  - ✓ Head unit dialing is functioning
  - ✓ Handset incoming/outgoing call audio is clear
  - ✓ Hands-free incoming/outgoing audio is clear
  - ✓ Automatic memory download is functioning<sup>1)</sup>

<sup>1)</sup>It may be necessary to store a test number in the telephone handset for this feature to operate. Stored numbers should be available for dialing from the head unit after automatic download.