## Air Conditioner / HVAC W203 Stepper Motor Repair PART 1 OF 3


http://mbworld.org/forums/c-class-w203/177068-noisy-air-conditioner-stepper-motor-replacement-clicking-hissing.html


 $\underline{http://mbworld.org/forums/c32-amg-c55-amg-w203/449471-famous-ac-clicking-noise-ac-footwell-damper-linkage-replacement-diy-details-steps.html}$ 

Great BIG thanks to Racin fool, liveniceguy and Wilsophia for the write up and pictures!!!


## DIY Starts on page 5 Upper Dash Removal page 25

W203 & 463 HVAC MB Technical Training Aid <a href="http://www.buellwinkle.com/HVAC-W203.pdf">http://www.buellwinkle.com/HVAC-W203.pdf</a>





# C320 Flap Actuation Motor Location



A32m1 - Blower motor

A32m2 - Charcoal filter flap motor

M2/5 - Fresh air / recirculating air flap positioning motor

M2/6 - Left blend air flap positioning motor

M2/7 - Right blend air flap positioning motor

M2/8 - Left defroster flap positioning motor

M2/9 - Right defroster flap positioning motor

M2/10 - Left footwell flap positioning motor

M2/11 - Right footwell flap positioning motor

M2/19 - Left fresh air flap positioning motor

M2/20 - Right fresh air flap positioning motor

#### Write up courtesy of Racin\_fool

http://mbworld.org/forums/members/48522-racin\_fool.html

Images courtesy of

liveniceguy

http://mbworld.org/forums/members/54770-liveniceguy.html

Wilsophia

http://mbworld.org/forums/members/215496-wilsophia.html

M2/19 information courtesy WaveyKat

http://mbworld.org/forums/members/19476-waveykat.html

Upper Dash Removal courtesy of <u>noreaga0221</u>

http://mbworld.org/forums/members/40139-noreaga0221.html

### Other additions courtesy of

vert

http://mbworld.org/forums/members/175496-vert.html

strder007

http://mbworld.org/forums/members/149731-strder007.html

v2k2c200

http://mbworld.org/forums/members/239153-y2k2c200.html


ferdiyan

http://mbworld.org/forums/members/231971-ferdiyan.html

#### Part numbers courtesy of me krazzdav

http://mbworld.org/forums/members/206007-krazzdav.html

| Item | 30  | A2038300233 Operating Lever Right                                       |
|------|-----|---|
| Item | 20  | A2038300133 Operating Lever Left  |
| Item | 115 | A2038300033 Operating Parts Kit   |
| Item | 110 | A2038300032 Linkage – Parts Kit, Footwell flaps without operating lever |
| Item | 310 | A2038201642 Stepper Motor / flap positioning motor (all same)           |
| Item | 320 | A2308216351 Blower Regulator  |
| Item | 330 | A2038202514 Electric Motor  |







Page 4 of 27 Compiled by krazzdav Initial write up by Racin\_fool Pics from liveniceguy and Wilsophia http://mbworld.org/

#### Item needed:

(1) Footwell flap linkage kit with 2 linkage arms (will edit with the part# tomorrow) \*Note - 99% of the time you do NOT need the A/c stepper motor\*

#### Tools you will need:

- (1) flashlight of some kind
- (1) 10mm socket (6 or 12pt)
- (1) 3/8" ratchet
- (1) 6-12" 3/8" extension
- (1) T35 Torx socket (3/8")
- (1) T20 torx screwdriver
- (1) plastic wedge
- (1) flat tip small pocket screwdriver (my most used tool)
- 1. Get in the driver's seat and turn off the car and the radio. I usually listen to the radio for a few minutes before removing it during the process.
- 2. Pop open the ashtray lid and empty the ashtray.

3. Use either the plastic wedge or your fingers to grab ahold of the front of the shifter surround trim and gently pull it up. Unplug the connectors from it and remove the shifter knob with it. (set all of this in the passenger seat so you won't misplace anything).





4. With the ashtray open, grab ahold of the front of the other trim piece around the shifter that goes from the ashtray to the cupholder. Pop this trim piece off and set it aside.



5. Next open the cupholder area and reach down inside it with either the small screwdriver or some small but long hook and remove the rubber insert where you would set a second cup/drink. (Most people seem to use this as a trashcan or coin holder). The

easiest way is to pry it loose at the rear and reach down inside with your fingers and just pull the insert out.



6. There is a small tab on the cupholder that you need to pull slightly up on to pop it loose and then it just twists out and can be removed and set aside. After this, you will notice 2 small tabs at the front of this section that can be pried loose and you can fold the front half of the cupholder section back exposing (2) of the (4) 10mm screws/bolts you must remove.





7. Open the center console lower area and empty it. Next, remove the lower cloth section mat at the bottom of this area and it will expose the remaining (2) 10mm bolts you must remove.



\*\*\*\*\*Notice: if you have the rear A/C option, you will need to remove the covers for it and then unscrew the rear a/c blower using the T20 torx screwdriver. Next unplug it and set it aside and then remove the (2) exposed black 10mm bolts.


(it is inside the center console; there are two small slots on the left and right front side of the top cover where a small flat screw driver was stuck in to release the latch)

Page 8 of 27

Compiled by krazzdav Initial write up by Racin\_fool Pics from liveniceguy and Wilsophia http://mbworld.org/



Page 9 of 27 Compiled by krazzdav Initial write up by Racin\_fool Pics from liveniceguy and Wilsophia http://mbworld.org/



8. \*\*\*\*Notice - engage the parking brake for you and your vehicles safety. Now you should see the black tab at the right rear of the shifter base. Press it forward and pull the gear selector back into neutral or drive. If you have not engaged the parking brake, do so NOW. Grab the small flat tip screwdriver and gently pry the two exposed tabs on the ashtray and pull the assembly up and out of the way. Also, don't forget to unplug it and then set it aside.



Page 10 of 27 Compiled by krazzdav Initial write up by Racin\_fool Pics from liveniceguy and Wilsophia http://mbworld.org/

