


- Parts list -

Mode	BM mode	BM overview	C 32 AMG V6-KOMPRESSOR
VIN/mod. des.	WDB2030651F469930	Catalog	65F
VIN	WDBRF65J44F469930	Group	47 FUEL SYSTEM
Assortment class	PC	Sub-group	015 FUEL TANK WITH DETACHABLE PARTS
Market			






























Copyright 2020-02-25 Daimler AG

Image ID: drawing_B47015000239

Item	Part number	Designation/additional information	Qty
10	A 203 470 55 01	FUEL TANK AMG USA MAPPS Code: M112+M32+M001+494; Plant information	1
20	A 203 470 00 40	TENSIONING STRAP TANK ATTACHMENT Fault location 47023	2
30	A 000 990 39 50	NUT-AND-WASHER ASSEMBLY TANK ATTACHMENT; M18X1.5	2
40	N 000000 003278	HEXAGON NUT TANK ATTACHMENT; M8	2
45	A 108 990 03 40	WINDOW	2

Item	Part number	Designation/additional information	Qty
50	A 203 470 17 20	FILLER NECK FUEL TANK Replaced by: A 203 470 19 20 Code: (M111/M112/M271/M272)+494/M272+M25+835; Fault location 47010	1
50	A 203 470 19 20 	FILLER NECK Replaces: A2034701720 Code: (M111/M112/M271/M272)+494/M272+M25+835; Fault location 47010	1
51	A 203 476 98 26 	* HOSE FROM FILLER NECK TO FUEL TANK Code: 494/921/835;	1
52	A 006 997 06 90 	* HOSE CLAMP MOLDED HOSE; 45-55 MM	2
53	A 230 476 87 26 	* HOSE TANK FOR SERVICE VENTING; 7,3 X 3 MM Code: (M111/M112/M271/M272)+494/(M611/M646)+921; [404, 409] ORDER BY THE METER	NB
53	A 140 476 53 26 	* FUEL HOSE FROM RESERVOIR TO VENT LINE FROM TANK; 290 MM Code: (M112/M271/M272)+494/M272+835;	1
53	A 230 476 87 26 	* HOSE TANK FOR SERVICE VENTING; 7,3 X 3 MM Code: (M112/M271/M272)+494; [404] ORDER BY THE METER	NB
54	A 006 997 18 90 	* HOSE CLAMP CONNECTING HOSE; 13-14.5 MM	3
54	A 006 997 18 90 	* HOSE CLAMP HOSE FASTENING; 13-14.5 MM Code: (M111/M112/M271/M272)+494;	2
54	A 006 997 18 90 	* HOSE CLAMP TO FUEL TANK; 13-14.5 MM	1
55	A 203 476 57 26 	* FUEL HOSE TANK BREATHING Code: (M111/M112/M271/M272)+494/(M611/M646)+921;	1
56	A 006 997 29 90 	* HOSE CLAMP HOSE FASTENING; 27.5 MM - 28.8 MM	2
56	A 005 997 86 90 	* BINDER LINE MOUNTING; 26.5 MM Code: (M111/M112/M271/M272)+494;	1
57	A 203 476 61 26 	* HOSE FILLER NECK TO CHARCOAL FILTER Code: (M111/M112/M271/M272)+494/M272+835; [402] NO LONGER AVAILABLE	1
58	A 006 997 18 90 	* HOSE CLAMP HOSE FASTENING; 13-14.5 MM Code: M111/M112/M271/M272;	1
59	A 000 995 66 65	SPACER, EXTENDABLE FUEL COMPENSATING LINE Code: (M111/M112/M271/272)+494;	1
60	A 000 476 04 36	HOSE BRACKET REGENERATION LINE Code: (M111/M112/M271/M272)+494;	1
64	A 000 990 03 11	COMBI-HEXAGON HEAD BOLT M6X18	3
65	A 001 990 12 36	SCREW FILLER NECK TO SIDE PANEL	1

Item	Part number	Designation/additional information	Qty
70	A 140 988 00 25	DOWEL FILLER NECK TO SIDE PANEL	1
80	A 203 997 14 81	GROMMET TANK FILLER NECK  Fault location 47020	1
90	A 211 470 04 05 	FILLER CAP TANK FILLER NECK  Code: (M112/M271/M272)+494/M272+835;  Plant information  Fault location 47011	1
100	A 168 471 06 79 	* SEALING RING FUEL FILLER CAP  Code: 494/835/921;  Fault location 47012	1
105	A 001 990 23 92	EXPANSION RIVET FUEL FILLER CAP; 5.2 MM  Code: M111/M271/M112/M272/M113+M55;	1
110	A 203 470 34 94	AUXILIARY PUMP WITH FLUID LEVEL SENSOR; MAPPS  Code: M112+M32+M001;  Plant information  Fault location 09001	1
120	A 203 470 17 41 	MOUNTING PLATE WITH FLUID LEVEL SENSOR; MAPPS/USA  Code: M112+M32+M001+494;  Plant information	1
125	A 163 542 28 18 	* PRESSURE SENSOR AT TANK  Code: (M112/M271/M272+(M25/M30))+(494/835+806);  Fault location 47147	1
130	A 002 477 30 01	FUEL FILTER FUEL FILTER TO TANK  Code: (M111/M112/M271)+494;	1
140	A 000 987 01 39	RUBBER BUMPER FUEL TANK	6
150	A 000 987 17 43	RUBBER SLEEVE FUEL TANK  Plant information	1
160	A 000 987 22 43	RUBBER SLEEVE FUEL TANK	1
170	A 203 471 00 50	BUSHING FUEL TANK	1
180	N 000000 003278	HEXAGON NUT M8	1
190	A 203 471 00 87	COVER FUEL TANK BOTTOM SIDE  Fault location 61209	1
195	N 914151 004015	SCREW COVER; 4X12	4
200	A 203 477 00 41	BRACKET FUEL FILTER  Code: -M55;	1
210	N 000000 001117	HEXALOBULAR BOLT FUEL FILTER BRACKET; M6X23  Code: -M55;	1
220	A 028 997 92 48	SEALING RING FUEL GAUGE SENDER UNIT	1

Item	Part number	Designation/additional information	Qty
230	A 000 476 00 66	RETAINING RING MOLDED HOSE  Code: -(M272+(M25/M30)+(929/494)/M272+M25+835);	1
280	A 001 990 80 54	UNION NUT MAINTENANCE OPENING  Code: -(M272+(M25/M30)+(929/494)/M272+M25+835);  Fault location 47161	2
282	A 203 471 01 79	SEAL RING MAINTENANCE OPENING Replaced by: A 203 471 03 79  Code: -(M272+(M25/M30)+(929/494)/M272+M25+835);  Fault location 47169	2
282	A 203 471 03 79	SEALING RING MAINTENANCE OPENING Replaced by: A 211 471 05 79 Replaces: A2034710179  Code: -(M272+(M25/M30)+(929/494)/M272+M25+835);  Fault location 47169	2
282	A 211 471 05 79	SEALING RING MAINTENANCE OPENING Replaces: A2034710379 Replaces: A2034710179  Code: -(M272+(M25/M30)+(929/494)/M272+M25+835);  Fault location 47169	2
300	A 000 476 37 26	HOSE TO FUEL FILTER; 11,5X3MM  Code: (M112/M271/M272)+494/M272+835;  [404] ORDER BY THE METER	NB
300	A 202 476 68 26	HOSE TO FUEL FILTER; 1000 MM  Code: M111/M112/M271/M272;  [404] ORDER BY THE METER	1
350	A 000 987 11 45	CAP INDUCTION PIPE AUXILIARY HEATING	1
360	N 916002 008100	CLAMP INDUCTION PIPE AUXILIARY HEATING	1