

“Next group”/“Previous group”

With the “*Next group*”/“*Previous group*” commands, you can select the next or previous group on the inserted audio DVD.

“Next folder”/“Previous folder”

With the “*Next folder*”/“*Previous folder*” commands, you can select a folder on the inserted CD/DVD in MP3 mode.

“Memory card”

With the “*Memory card*” command, you can switch to the PCMCIA card on the COMAND system.

“DVD video”

With the “*DVD video*” command, you can start a video DVD on the COMAND system.

“Hard disk”

With the “*Hard disk*” command, you can change to the internal hard disk (Music Register) of COMAND.

External equipment (AUX)

Audio aux

You can use the “*Audio Aux*” command to activate the aux input.

Voice Control

Command list

Command list

In the Command list section, you will find all the main commands for operating voice control. The commands available to you depend on the vehicle's equipment.

i *Some functions have several voice commands to facilitate operation. These are grouped together between the separator lines in the list and can be used interchangeably.*

General commands

- Yes
- Correct
- Okay
- Cancel
- No
- Pause
- Address book
- MP3
- CD changer
- CD

• Navigation	• Continue
• Route guidance	• Go forward
• Nav	• Next page
• DVD video	• Previous page
• DVD audio	• Go back
• Radio	• Back
• Satellite radio / Sirius *	• Help radio
• Phone	• Help phone/help telephone
• Messages	• Help address book
• Video	• Help CD changer
• Correction	• Help DVD
• Wrong	• Help DVD changer
• Incorrect	• Help DVD audio
• Help	• Help DVD audio changer
• Help functions	• Help MP3
• Help devices	• Help MP3 changer
• Help voice control [system]	• Help navigation
• Help voice control/voice control help	• Help route guidance
• General help	• Help nav
• 0 - 9	
• Letters of the alphabet	

Voice Control Command list

Phone commands

- Phone
- Telephone on /phone on
- Save
- Save PIN/PIN code
- Save name
- Save number
- Save phone number
- Dial PIN
- Dial PIN code
- Dial PIN number
- Dial number
- Dial phone number
- Confirm
- Confirm PIN
- Confirm PIN code
- Confirm PIN number
- Confirm number
- Confirm phone number

- Enter PIN
- Enter PIN code
- Enter PIN number
- List phone book
- Read out phone book
- Redial
- Redial last number
- Redial last phone number
- Correction
- Incorrect
- Wrong PIN
- Wrong PIN code
- Wrong PIN number
- Wrong number
- Wrong phone number
- Delete
- Delete PIN
- Delete PIN code
- Delete PIN number
- Delete name
- Delete phone number

Voice Control

Command list

Navigation commands	
<ul style="list-style-type: none"> Navigation Route guidance Nav 	<ul style="list-style-type: none"> Zoom out Zoom out of map Zoom out completely Zoom in completely
<ul style="list-style-type: none"> Guidance instructions on Switch guidance instruction/instructions on Switch route guidance instruction/instructions on Listen to guidance instruction/instructions 	<ul style="list-style-type: none"> Enter state Change state Enter province Change state Enter destination area Another state Last destinations
<ul style="list-style-type: none"> Guidance/route guidance instructions off Switch off guidance/route guidance instructions Mute guidance/route guidance instructions 	<ul style="list-style-type: none"> Enter town Enter name of town
<ul style="list-style-type: none"> House number Enter house number 	<ul style="list-style-type: none"> Spell town Spell name of town
<ul style="list-style-type: none"> Map Show map Map on/switch on map 	<ul style="list-style-type: none"> District Enter district Center Enter center
<ul style="list-style-type: none"> Zoom in Zoom in on map 	
	<ul style="list-style-type: none"> Spell district Spell center Point(s) of interest/POI(s) Enter point(s) of interest/POI(s)
	<ul style="list-style-type: none"> Street Enter street Name of street Enter name of street
	<ul style="list-style-type: none"> Spell street Spell name of street Enter destination
	<ul style="list-style-type: none"> Save destination Save address
	<ul style="list-style-type: none"> Start route guidance/routing/destination guidance Begin route guidance Begin destination guidance Continue route guidance/destination guidance

Voice Control

Command list

<ul style="list-style-type: none"> Cancel route guidance/navigation/nav/destination guidance Exit route guidance/navigation/nav/destination guidance Stop route guidance/navigation/nav/destination guidance Terminate route guidance/navigation/nav/destination guidance Next gas station Next Mercedes-Benz Service Next workshop Next MB service Next hospital Next car park Next restaurant 	<p>Address book commands</p> <ul style="list-style-type: none"> Address book List address book Read out/play address book Delete address book Spell entry Spell name Find entry Delete name List destination memory Read out/play destination memory <voice_name_tu> <voice_name_ad> car <voice_name_ad> car phone <voice_name_ad> landline <voice_name_ad> landline phone <voice_name_ad> landline phone <voice_name_ad> mobile <voice_name_ad> mobile phone <voice tag> mobile phone <voice tag> work 	<ul style="list-style-type: none"> <voice_name_ad> home Work Office Company/business Car Car phone Landline Landline phone Landline phone Mobile Mobile phone Work car Work car phone Car phone work/office/business/company Work/office/business/company/landline Work/office/business/company/landline telephone/phone Landline telephone/phone work/office/business/company
--	--	---

Voice Control

Command list

- Work/office/business/company/mobile
- Work/office/business/company/phone
- Mobile phone work/office/business/company
- Home
- Home car
- Home car phone
- Car phone home
- Home landline
- Home landline telephone/phone
- Landline telephone/phone home
- Home mobile
- Home mobile phone
- Mobile phone home
- Dial name
- Save name
- Save number
- Save telephone/phone number

- Accept
- Accept PIN
- Accept name
- Accept phone number
- Okay
- Finished
- <1> - <6>
- Select 1 - select 6
- Number 1 - number 6

Audio and video commands

- Audio
- Radio
- Radio on
- 87.7 megahertz - 107.9 megahertz
- 87 point 7 to 107 point 9
- 87 point 7 megahertz to 107 point 9 megahertz
- Frequency 87.7 - frequency 107.9
- Frequency 87 point 7 - frequency 107 point 9
- Frequency 87 point 7 megahertz - frequency 107 point 9 megahertz
- FM
- AM
- Weatherband
- Next station
- Other station
- Station search
- Station <voice_tag>
- Delete station

Voice Control

Command list

<ul style="list-style-type: none"> • Save station • Select station • List station list • Read out station list • Delete station list • Previous station • Last station 	<ul style="list-style-type: none"> • Next category • Previous category • Category <category name> • Select category • List category list • Read out category list • Previous category • Last category 	CD changer <ul style="list-style-type: none"> • CD changer • Next CD • Other CD • Previous CD • Last CD • Next track • Other track
Satellite Radio* (SIRIUS) <ul style="list-style-type: none"> • Satellite Radio* on/SIRIUS on • Next channel • Other channel • Channel <voice_tag> • Delete channel • Save channel • Select channel • List channel list • Read out channel list • Delete channel list • Last channel • Previous channel 		<ul style="list-style-type: none"> • Previous track • Last track • Repeat/replay track • CD 1 to CD 6 • CD number 1 - CD number 6 • Track 1 - Track 99 • Track number 1 - Track number 99

Voice Control

Command list

MP3	Hard disk	DVD audio
<ul style="list-style-type: none">• MP3• MP3 changer (on)	<ul style="list-style-type: none">• Hard disk• Music register	<ul style="list-style-type: none">• DVD audio• DVD audio changer on
<ul style="list-style-type: none">• Next MP3• Other MP3	Memory card	<ul style="list-style-type: none">• Next DVD audio• Other DVD audio
<ul style="list-style-type: none">• Previous MP3• Last MP3• Repeat/replay MP3	<ul style="list-style-type: none">• Memory card	<ul style="list-style-type: none">• Previous DVD audio• Last DVD audio
<ul style="list-style-type: none">• Next directory• Other directory		<ul style="list-style-type: none">• Next directory• Other directory
<ul style="list-style-type: none">• Previous directory• Last directory		<ul style="list-style-type: none">• Previous directory• Last directory
<ul style="list-style-type: none">• Next track• Other track		<ul style="list-style-type: none">• Next group• Other group
<ul style="list-style-type: none">• Previous track• Last track• Repeat/replay track		<ul style="list-style-type: none">• Previous group• Last group
<ul style="list-style-type: none">• Track 1 - Track 99• Track number 1 - Track number 99		<ul style="list-style-type: none">• Group 1 - 9• Group number 1 - 9
<ul style="list-style-type: none">• MP3 1 - MP3 6• MP3 number 1 - MP3 number 6		<ul style="list-style-type: none">• Next track• Other track