





Item	Designation
<u>A2/12</u>	Rear window antenna amplifier module
<u>A2/12x1</u>	Rear window antenna amplifier module connector
<u>F1</u>	Left fuse box
<u>F1f24</u>	Fuse 24
<u>F4</u>	Rear fuse box
<u>F4f60</u>	Fuse 60
<u>H4/1</u>	Left door speaker group
<u>H4/1h1</u>	Tweeter
<u>H4/1h2</u>	Woofers
<u>H4/1x1</u>	Left door speaker group connector
<u>H4/2</u>	Right door speaker group
<u>H4/2h1</u>	Tweeter
<u>H4/2h2</u>	Woofers
<u>H4/2x1</u>	Right door speaker group connector
<u>H4/17</u>	Bass module loudspeaker
<u>H4/17x1</u>	Bass speaker connector 1
<u>H4/17x2</u>	Bass speaker connector 2
<u>H4/27</u>	Center cockpit speaker (Centerfill)
<u>H4/27x1</u>	Speaker connector
<u>N70</u>	Overhead control panel control module
<u>N93/1</u>	Audio gateway control module
<u>U461</u>	Valid for AGW speaker
<u>W6</u>	Ground (left wheelhousing in trunk)
<u>X18</u>	Cockpit wiring harness and FFS [RBA] connector
<u>X25/8</u>	Overhead control panel and FFS [RBA] connector
<u>X30/5</u>	Left voltage distributor (CAN) connector
<u>Z4/3</u>	Circuit 30 connector sleeve
<u>Z35/10</u>	D2B/MOST wake-up signal connector sleeve