

Function:	Fuse Number: (Black = Fuse / Yellow = Diode)
4-Wheel drive, AMG	105 134 139 149
Automatic transmission	43 45 49 51 57
A/C system / heater	52 53 103 143 166
Airbag / Restraint System	112 115 119
Anti-theft alarm system	129
CBC / SAM	21 40 42 63 68 158 165
Central locking	106 167
Central console or 115/230V socket	117
Cigar lighter / socket front	170 124
Control panel	143 144
Damper adjustment	114
Diagnosis	27 110
Distronic / FCW	47 70 107 169
Driving School	65
Door functions	154 156 161 163
Electronic ignition lock	132 160
Emergency call system	108
ESP, parking brake	23 24 72 78
ETC/DSRC Card Reader Japan	166
Exterior lighting	158 165 169
Fanfare horn	42
Fuse pump	159
Hazard warning flashers / ECO	158 165 169
Headlights	21 22 40 48 64
Heated rear windows	121
Hybrid	30 31 46 50 53 57 61 63 66 76 78 102 151 153 155
Instrument cluster	111 152
Motor diesel	29 57 67 105 135
Motor electronics	26 27 28 29 30 31 43 54 55 56 41 69 71
MBUX, navigation, steering wheel	109 144 145 146 148 152 168 169 170
Overhead control panel	140
Parktronic system	171
Power socket / USB	123 125
Radio system	104 131 152
Rotary light switch	142
Seat driver	116 136 138
Seat passenger	116 136 138
Socket, load compartment	201
Starter	73 74 75
Steering column lock	132 160
Taxi	201 205 207
Tilting / sliding roof	113
Tyre pressure monitoring system (TPMS)	167
Trailer hitch	202 208 209 210 211
Windshield wipers front, rain sensor	42 44 169
Wipers rear	106

