

**Locations**

S93/3 SOS pushbutton switch



P82.95-2370-02

	TELE AID pushbutton, location	The SOS pushbutton switch (S93/3) is located in the left section of the overhead control panel (N70).	
	TELE AID pushbutton, task	<ul style="list-style-type: none"> <li>● Triggering a manual TELE AID emergency call</li> <li>● Signaling TELE AID operating states</li> </ul>	
	TELE AID pushbutton, design	<ul style="list-style-type: none"> <li>● Integrated LED to night illumination (circuit 58d)</li> <li>● 2 Two integrated LED's as display for operating condition</li> <li>● Cap for protecting against unintentional actuation</li> </ul>	
	TELE AID pushbutton, function		GF82.95-P-4101-04A