

P82.62-2295-09

Shown on model 209.3

- 1 Center nozzle cover
- 2 Electrical connector


3 Catch lugs

H4/27 Cockpit center speaker (Centerfill)

Modification notes

11.2.04	Disconnect/connect/remove ground lead from battery		
---------	--	--	--

	Remove/Install		
1	Unclip center nozzle cover (1)		*110589035900
2	Detach electrical connector (2) and remove center nozzle cover (1).		
3	Unclip center cockpit speaker (centerfill) (H4/27) and remove		Press detent lugs (3) outwards.
4	Install in the reverse order		
5	Perform function check		



110 589 03 59 00

Mounting wedge