



P68.20-2588-09

- 1 Center console cover
- 2 Ashtray housing

4 Bolts

5 Clutches

	<p>Remove/Install</p>		
<p>⚠ Danger!</p>	<p>Risk of explosion from explosive gas. Risk of poisoning and caustic burns from swallowing battery electrolyte. Risk of injury through burns to skin and eyes from battery acid or when handling damaged lead-acid batteries</p>	<p>No fire, sparks, naked flames or smoking. Wear protective gloves, acid-resistant clothing and safety glasses. Pour battery electrolyte only into suitable and appropriately marked containers.</p>	<p>AS54.10-Z-0001-01A</p> <p>AR54.10-P-0003Q</p>

1 Center console cover
2 Ashtray housing

4 Bolts

5 Clutches

	Remove/Install		
<p> Danger!</p> <p>1</p> <p></p>	<p>Risk of explosion from explosive gas. Risk of poisoning and caustic burns from swallowing battery electrolyte. Risk of injury through burns to skin and eyes from battery acid or when handling damaged lead-acid batteries</p> <p>Disconnect ground cable of battery</p> <p>Notes on battery</p>	<p>No fire, sparks, naked flames or smoking. Wear protective gloves, acid-resistant clothing and safety glasses. Pour battery electrolyte only into suitable and appropriately marked containers.</p> <p>All models</p>	<p>AS54.10-Z-0001-01A</p> <p>AR54.10-P-0003Q</p> <p>AH54.10-P-0001-01A</p>
2	Remove ashtray housing (2) at front center console		AR68.20-P-2400P
3	Remove screws (4).		
4	Remove cover from center console (1)		
5	Disconnect couplings (5) at upper control panel control module (N72/1)		
6.1	Disconnect couplings at automatic heater and air conditioning	With code (581b) convenience automatic air conditioning	
6.2	Disconnect couplings at automatic air conditioning	Except code (581b) convenience automatic air conditioning	
7	Install in the reverse order		
8	Perform basic programming		AR00.19-P-0200Q
9	Read diagnostic trouble code memory and erase	STAR diagnosis tool.	
10	Check for proper function		