

Practical hints

What to do if ...

Display message	Possible cause/consequence	Possible solution
P Gear Selector Lever In P Position	<p>You have tried to start the engine with the KEYLESS-GO* start/stop button with the gear selector lever not in position P.</p> <p>You have tried to turn off the engine with the KEYLESS-GO* start/stop button with the gear selector lever not in position P.</p>	<p>► Place the gear selector lever in position P.</p>
P/N Please Shift To N or P	<p>You have tried to start the engine with the KEYLESS-GO* start/stop button while the gear selector lever was in position R or D.</p>	<p>► Place the gear selector lever in position P or N. Make sure the brake pedal is depressed.</p>
PRE-SAFE Inoperative See Operator's Manual	<p>PRE-SAFE® itself has failed. All other occupant safety systems, such as the air bags, are still available.</p> <p>If ESP® and PRE-SAFE® malfunction messages are displayed simultaneously, PRE-SAFE® has been deactivated as a result of these malfunctions. All other occupant safety systems, such as the air bags, are still available.</p>	<p>► Contact an authorized Mercedes-Benz Center as soon as possible.</p>