

Power tilt/sliding sunroof

Fully opening (Express-open) and closing (Express-close) the power tilt/sliding sunroof	Synchronizing the power tilt/sliding sunroof	► Move and hold the sunroof switch in the direction of arrow ③ until the tilt/sliding sunroof is fully raised at the rear. Keep holding the sunroof switch in the direction of arrow ③ for approximately 1 second.
	The tilt/sliding sunroof must be synchronized	► Check the Express-open feature (▷ page 214). If the tilt/sliding sunroof opens completely, the roof is synchronized. Otherwise repeat the above steps.
► To open or close the tilt/sliding sunroof, move the sunroof switch past the resistance point in the direction of arrow ① to ② and release.	• after the battery has been disconnected or discharged	► If the tilt/sliding sunroof has been closed manually (▷ page 400)
The tilt/pop up roof opens or closes completely.	• after the tilt/sliding sunroof has been closed manually (▷ page 400)	• after a malfunction • if the tilt/sliding sunroof does not open smoothly
		► Remove the respective fuse from the main fuse box (▷ page 428).
► Move the sunroof switch in any direction.		► Reinsert the fuse in the main fuse box.
	Stopping the power tilt/sliding sunroof during Express-operation	► Switch on the ignition (▷ page 38).
	<i>If the movement of the tilt/sliding sunroof is blocked during the closing procedure, the tilt/sliding sunroof will stop and reopen slightly.</i>	

i *If the movement of the tilt/sliding sunroof is blocked during the closing procedure, the tilt/sliding sunroof will stop and reopen slightly.*