AR68.30-P-4785T Remove/install trim on rear center section 19.9.01


MODEL 211.0

Rear center section trim
Spare wheel well cover

3 Expansion rivet

E18/4 Right luggage compartment lamp E18/5 Left luggage compartment lamp





P68.30-2486-04

Modification notes

8.1.04 Disconnect/connect/remove ground lead from battery		
---	--	--

XX	Remove/Install		
1	Switch off right luggage compartment lamp (E18/4) and left luggage compartment lamp (E18/5) by locking trunk lid lock with suitable screwdriver	i Installation: Actuate opening handle on outer trunk lid to unlock trunk lid lock	
2	Remove right luggage compartment lamp (E18/4) and left luggage compartment lamp (E18/5)		
3	Remove expansion rivets (3) and remove rear center section trim (1) from trunk		
4	Install in the reverse order		