



P68.30-3043-09

Shown on vehicle with code (889) Keyless
Go and with code (881) Remote trunk
closing (RTC)

- 1 Trunk lid
- 2 Bolts
- 3 Cover
- 4 Trunk lid paneling
- 5 Expanding rivets

- E18/1 Luggage compartment lamp
- S62/21 Trunk lid keyless go button
(with code (889) Keyless go)

- S62/26 RTC button
(with code (881) Remote trunk
closing (RTC))

	Remove/Install		
1	Open trunk lid (1)	See Operating Instructions	
2	Unscrew bolts (2)		*WH58.30-Z-1007-20A
3	Loosen cover (3) until electrical connectors are accessible		
4.1	Disconnect electrical connector from trunk lid keyless go button (S62/21)	Only on vehicles with code (889) Keyless go	
5.1	Disconnect electrical connector from RTC button (S62/26)	Only on vehicles with code (881) Remote trunk closing (RTC)	
6	Disconnect electrical connector from luggage compartment lamp (E18/1) and remove cover (3)		
7	Remove expansion rivets (5)		
8	Remove trunk lid paneling (1)		
9	Install in the reverse order		
10	Perform function check		

Commercially available tools

Number	Designation
WH58.30-Z-1007-20A	Cordless drill/driver