


AR42.20-P-0520-02TX	Relieve load on automatic cable slack adjuster		
---------------------	--	--	--

- 1 Lift middle holddown clip (arrow) using a screwdriver.
i The cable slack adjuster then adjusts itself automatically.



P42.20-0212-01