



P32.22-2299-79

A9/1	AIRmatic compressor unit	N49	Steering angle sensor	Y52	Right front axle damping valve unit
A1p13	Multifunction display	N51	AIRmatic with ADS control unit	Y52/1	Right front suspension strut AIRmatic valve unit
B7	AIRmatic pressure sensor	N72s18	Level adjustment switch	Y53	Left rear axle damping valve unit
B22/3	Rear axle level sensor	N72s25	Comfort and sport switch	Y53/1	Left rear suspension strut AIRmatic valve unit
B22/8	Left front level sensor	Y36/6	AIRmatic central reservoir charge valve	Y54	Right rear axle damping valve unit
B22/9	Right front level sensor	Y51	Left front axle damping valve unit	Y54/1	Right rear suspension strut AIRmatic valve unit
B24/3	Left front body lateral acceleration sensor	Y51/1	Left front suspension strut AIRmatic valve unit		
B24/4	Right front body lateral acceleration sensor				
B24/6	Right rear body lateral acceleration sensor				