


MODEL 216, 219, 221

## Shown on model 219

- 1 Bolts  
2 Electrical connector

- M21/1m1 Mirror up/down adjustment motor  
M21/1m2 Mirror in/out adjustment motor  
M21/2m1 Mirror up/down adjustment motor  
M21/2m2 Mirror in/out adjustment motor



P88.70-2357-04

☒ ☒	Remove/install		
1	Remove mirror glass		AR88.70-P-9020TX
2	Remove bolts (1)		
3	Remove mirror up/down adjustment motor (M21/1m1) and mirror in/out adjustment motor (M21/1m2) or mirror up/down adjustment motor (M21/2m1) and mirror in/out adjustment motor (M21/2m2)		
4	Disconnect electrical connector (2)		
5	Install in the reverse order		