



P68.20-3246-09

1 Rear center console.
2 Front stowage compartment
3 Bolts

4 Rear storage compartment
5 Insert

6 Nut
7 Electrical connectors

	Remove/Install		
1	Remove left or rear seat cushion		AR91.12-P-1020TX
2	Open cover on front stowage compartment (2)		
3	Remove bolts (3)		
4	Open rear stowage compartment (4) and remove insert (5)		
5	Unscrew nut (6)		
6	Forcefully pull rear center console (1) upward in front arrow (arrow A)	When doing this, the rear center console (1) is unclipped from the front stowage compartment (2).	
7	Remove rear center console (1) from transmission tunnel and turn to side until the connector package (arrow B) is accessible		
8	Pull connector package (arrow B) out of rear center console (1) and disconnect electrical connectors (7)	Number of electrical connectors (7) according to equipment.	
9	Remove rear center console (1)		
10	Install in the reverse order		