

P54.15-2676-09

Location

F33 Rear pre-fuse box
 F34 Interior fuse box

N10/1 Driver-side SAM control unit with fuse and relay module


N10/2 Rear SAM control unit with fuse and relay module

Location up to and including code 806 Model year 2006

F30 Second battery additional fuse
 K41/1 NECK-PRO head restraints relay (as of code 805 Model year 2005)
 K57/2 Additional battery relay

i The 2nd battery additional fuse is fastened to the wiring loom next to the additional battery (G1/7) and is designed as a circuit breaker (bimetal fuse).

i The NECK-PRO head restraints relay is located in the wiring harness of the frame floor group on the driver-side at the entrance.



P54.10-2488-06




Location up to and including code 806
Model year 2006

Valid for model 219.376 (CLS 55 AMG)
up to and including code 806 Model year
2006

F32 Front prefuse

F82A FP fuse
F82B Air injection fuse
K17 Air injection relay

K27/1 Fuel pump relay
K27/2 Fuel pump 2 relay (only with
code 806 Model year 2006)



P54.15-2836-09

Location as of code 807 Model year
2007

K41/1 NECK-PRO head restraints relay

K67 AIRmatic relay (only with code
(489) Airmatic (semi-active air
suspension))

K74 Heated rear window relay



P54.15-2837-07

Location as of code 807 Model year
2007

F32 Front prefuse

N118 Fuel pump control unit (engine
272.985 only)

Location as of code 807 Model year 2007
engine 156.983 (CLS 63 AMG)only

N118/3 Left fuel pump control unit
N118/4 Right fuel pump control unit



P54.15-3034-04

Fuse assignment of fuse and relay box in
left engine compartment

Up to and including code (805) Model year
2005

GF54.15-P-1256-03TX

		As of code (807) Model year 2007	GF54.15-P-1256-03TXB
	Fuse assignment of fuse box in interior compartment on driver's side	Up to and including code (805) Model year 2005 with code (806) Model year 2006 As of code (807) Model year 2007	GF54.15-P-1256-04TX GF54.15-P-1256-04TXA GF54.15-P-1256-04TXB
	Fuse assignment of fuse and relay box in trunk	Up to and including code (805) Model year 2005 with code (806) Model year 2006 As of code (807) Model year 2007	GF54.15-P-1256-06TX GF54.15-P-1256-06TXA GF54.15-P-1256-06TXB
	Fuse assignment of front prefuse box		GF54.15-P-1256-07TX
	Fuse assignment of rear prefuse box	Up to and including code (805) Model year 2005 with code (806) Model year 2006 As of code (807) Model year 2007	GF54.15-P-1256-08TX GF54.15-P-1256-08TXA GF54.15-P-1256-08TXB
	Relay assignment of fuse and relay box in left side of engine compartment		GF54.15-P-1257-03TX
	Relay assignment of fuse and relay box in trunk		GF54.15-P-1257-04TX