

## Model 257, 290

## Shown on model 257.3

F32/3	Engine compartment prefuse box
K40/6	Driver-side fuse and relay module
K40/8	Engine fuse and relay module



P54.15-3938-06



P54.15-3939-09

## Shown on model 257

F1/3Passenger-side A-pillar fuse boxF32/4Vehicle interior prefuse box

K40/5 Rear fuse and relay module

## With code B01 (48V technology), shown on model 257

F153/2 Engine compartment 48 V onboard electrical system fuse box



P54.15-3941-04

Assig	gnment of passenger-side A-pillar fuse	F1/3	GF54.15-P-1256-48FR
	e assignment of prefuse box in engine partment	F32/3	GF54.15-P-1256-25FR
Fuse	assignment on interior prefuse box	F32/4	GF54.15-P-1256-26FR
	d electrical system in engine compartment	Model 257, 290 with code B01 (48V technology) F153/2	GF54.15-P-1256-46FR
Assiç	gnment of rear fuse and relay module	K40/5	GF54.15-P-1256-30FR
Assig	, , , , , , , , , , , , , , , , , , ,	K40/6	GF54.15-P-1256-49FR
Assiç	gnment of engine fuse and relay module	K40/8	GF54.15-P-1256-32FR