

Model 207.4



P77.30-2595-79

| 1 | Soft top bow hydraulic cylinder | N72/1s4 | Rear head restraint button (up to 31.05.2013, as of |
|--------|---|----------|--|
| | | | 01.06.2013 with transmission 711, 716) |
| 2 | Soft top actuation hydraulic cylinder | N72/4 | Left lower control panel (as of 01.06.2013 with |
| | | | transmission 722.9, 725) |
| 3 | Soft top compartment lid hydraulic cylinder | N72/4s18 | Rear head restraint button (as of 01.06.2013 with |
| | | | transmission 722.9, 725) |
| 4 | Soft top lock hydraulic cylinder | N73 | Electronic ignition switch control unit |
| A1 | Instrument cluster | S12 | Parking brake indicator switch |
| A1p13 | Multifunction display | S52/8 | Left head restraint "down" limit switch |
| A7/5 | Soft top control hydraulic unit | S52/9 | Right head restraint "down" limit switch |
| A7/5b1 | Temperature sensor | S84 | Soft top control switch |
| A7/5m1 | Convertible top control hydraulic unit electric motor | S84s4 | Draft stop and wind deflector button |
| A7/5y1 | Solenoid valve 1 | S84s5 | Power windows central operating switch |
| A7/5y2 | Solenoid valve 2 | S84/3 | Soft top "open" limit switch |
| A7/5y3 | Solenoid valve 3 | S84/9 | Variable soft top compartment limit switch |
| A7/5y4 | Solenoid valve 4 | S84/11 | Left soft top "locked" limit switch |
| B14 | Outside temperature sensor | S84/13 | Soft top compartment cover switch group (open/close) |
| N10/1 | Front SAM control unit with fuse and relay module | S84/15 | Soft top bow "down/up" limit switch |
| N10/2 | Rear SAM control unit with fuse and relay module | S84/18 | Soft top limit switch in catch position |
| N22/6 | Rear control unit | S84/19 | Soft top bow "locked" limit switch |
| N69/1 | Left front door control unit | S84/22 | Soft top compartment cover in catch position limit |
| | | | switch |
| N69/2 | Right front door control unit | S84/23 | Soft top compartment cover "locked" limit switch |
| N72/1 | Upper control panel control unit | | |



P77.30-2596-79

| M10/3 | Left front door power window motor | M14/7 | Trunk lid central locking motor |
|-------|-------------------------------------|---------|---|
| M10/4 | Right front door power window motor | M14/7s1 | Trunk lid rotary tumbler switch |
| M10/5 | Left rear power window motor | M28/14 | Actuator motor for head restraint drive in rear |
| | | | passenger compartment |
| M10/6 | Right rear power window motor | M96/2 | Wind deflector actuator motor (only with code (288) |
| | | | AIRCAP) |

| Component description for instrument cluster | A1 | GF54.30-P-6000CA |
|---|---|------------------|
| Component description for front SAM control unit with fuse and relay module | N10/1 | GF54.21-P-6070CA |
| Component description for rear SAM control unit with fuse and relay module | N10/2 | GF54.21-P-6030CA |
| Rear control unit, component description | N22/6 | GF54.21-P-4134CA |
| Component description for left front door control unit | N69/1 | GF72.29-P-6001CA |
| Component description for right front door control unit | N69/2 | GF72.29-P-6009CA |
| Upper control panel control unit, component description | N72/1 | GF54.21-P-6040CA |
| Lower control panel, component description | Model 207.4 with transmission 722.9 as of model year 2014 Model 207.4 with transmission 725 as of model year 2014 N72/4 | GF54.25-P-4270CA |
| Component description for the electronic ignition lock control unit | N73 | GF80.57-P-6001CA |
| Table of contents for function description of soft top | | GF77.30-P-0999CA |