

Item	Designation	Coordinates
<u>A0</u>	Color code key	15L
<u>A2</u>	Radio	10L
<u>A40/3</u>	COMAND control unit	10L
<u>N10/1</u>	Front SAM control unit with fuse and relay module	6L
<u>N10/2</u>	Rear SAM control unit with fuse and relay module	3L
<u>U12</u>	Valid for left-hand drive vehicles	3C
<u>U13</u>	Valid for right-hand drive vehicles	3C
<u>W15/5</u>	Left front footwell ground point	4E
<u>W15/7</u>	Right front footwell ground point	4F
<u>X11/4</u>	Diagnostic connector	8A
<u>CAN D</u>	Diagnostic CAN	6K