


Transmission 722.9



P27.00-2136-09

- 3 Oil pan
- 3b Bolts
- 32 Solenoids

- 33 Seal
- 34 Oil filter

Warning	<b>Risk of injury.</b> Skin or eye injuries may result when handling hot or glowing objects.	Wear protective gloves, protective clothing and safety glasses, if necessary.	AS00.00-Z-0002-01A
	<b>Risk of death</b> caused by vehicle slipping or toppling off of the lifting platform.	Align vehicle between vehicle lift columns and position the four support plates at the vehicle lift support points specified by the vehicle manufacturer.	AS00.00-Z-0010-01A
	<b>Risk of death</b> caused by vehicle slipping or toppling off during lifting	Only lift vehicle at the lift support points specified by the vehicle manufacturer.	AS00.00-Z-0032-01A
Caution	<b>Risk of injury</b> to skin and eyes due to handling of transmission oil. Health risk caused by swallowing transmission oil	Wear protective gloves, protective clothing and safety glasses. Do not pour transmission oil into beverage bottles.	AS00.40-Z-0001-01A
	Notes on automatic transmission		AH27.19-P-0001-01NKB
	<b>Remove</b>		
1	Shift automatic transmission into neutral position.		
2	Switch electronic ignition lock control unit to position "0".		
3 	Lift vehicle with lifting platform.		AR00.60-P-1006A  The vehicle must be horizontal in the longitudinal and transverse direction on the vehicle lift.
4     	Remove auxiliary oil pump from automatic transmission.		Transmission 722.9 (except 722.930/931/971) Vehicle with CODE B03 (ECO start/stop function) Model 166, 292 with transmission 722.9 (except 722.931) AR27.30-P-0651GQ Model 172, 212, 218 with transmission 722.9 (except 722.930/931/971) AR27.30-P-0651EL Model 204, 207 with transmission 722.9 (except 722.930) AR27.30-P-0651FH Model 205 with transmission 722.9 (except 722.930) AR27.30-P-0651LW

