

- Parts list -

Mode : MD mode Mod. des. overview : PASSENGER CAR,SEDAN,MODEL YEAR 82 UP TO CHASSIS 015885

FIN/MD : WDB 1231331A248534 Catalog : 68K

VIN : WDBAB33C4FA248534 Major assembly :


Sales designation : 300 D TURBO Major assembly MD :

Assortment class : Car Group : 68 - COVERING

Market : North America Subgroup : 030 - EXPANSION PLUGS,GROMMETS

| Item no. | Part number | Designation/description | Quantity | Version |
|----------|-----------------|--|----------|---------|
| 5 | A 123 987 05 44 | EXPANSION PLUG LATERAL REAR BUMPER TO BODY | 002 | |
| 8 | A 116 987 00 44 | EXPANSION PLUG WHEELHOUSES, REAR FENDERS | 002 | |
| 11 | A 110 987 10 44 | EXPANSION PLUG IN FLOOR,FRONT | 002 | |
| 14 | A 110 987 08 44 | EXPANSION PLUG IN FRONT PANEL PILLAR,OUTSIDE; FOR SLIDING ROOF HOSE | 002 | |
| 17 | A 113 987 00 44 | EXPANSION PLUG SIDE MEMBER, BOTTOM OUTSIDE | 004 | |
| 17 | A 113 987 00 44 | EXPANSION PLUG PAINT RUN-OFF HOLE IN REAR PANEL | 002 | |
| 17 | A 113 987 00 44 | EXPANSION PLUG REAR SIDE MEMBER | 006 | |
| 17 | A 113 987 00 44 | EXPANSION PLUG MAIN FLOOR,LATERAL | 006 | |
| 17 | A 113 987 00 44 | EXPANSION PLUG CROSS MEMBER IN THE REAR, RIGHT | 001 | |
| 17 | A 113 987 00 44 | EXPANSION PLUG IN FLOOR BELOW REAR SEAT BENCH | 001 | |
| 17 | A 113 987 00 44 | EXPANSION PLUG REAR PANEL | 001 | |
| 17 | A 113 987 00 44 | EXPANSION PLUG REAR BODY PANEL,BOTTOM OUTSIDE | 004 | |
| 17 | A 113 987 00 44 | EXPANSION PLUG PAINT RUN-OFF IN FLOOR,LATERAL | 002 | |
| 17 | A 113 987 00 44 | EXPANSION PLUG REAR WHEELHOUSE,INSIDE | 006 | |
| 17 | A 113 987 00 44 | EXPANSION PLUG REAR WHEELHOUSE,OUTSIDE | 010 | |
| 17 | A 113 987 00 44 | EXPANSION PLUG REAR END PILLAR | 008 | |
| 20 | A 116 987 02 44 | EXPANSION PLUG ANTENNA CABLE IN FRONT PANEL PILLAR | 001 | |
| 23 | A 110 987 05 44 | EXPANSION PLUG ON MAIN FLOOR | 002 | |
| 23 | A 110 987 05 44 | EXPANSION PLUG IN FLOOR BELOW REAR SEAT BENCH | 001 | |
| 23 | A 110 987 05 44 | EXPANSION PLUG AT SIDE MEMBER,OUTSIDE | 012 | |
| 23 | A 110 987 05 44 | EXPANSION PLUG IN SPARE WHEEL WELL | 001 | |
| 23 | A 110 987 05 44 | EXPANSION PLUG REAR END PILLAR | 006 | |
| 23 | A 110 987 05 44 | EXPANSION PLUG PAINT RUN-OFF IN FLOOR,LATERAL | 002 | |

| | | | |
|----|-----------------|--|-----|
| 23 | A 110 987 05 44 | EXPANSION PLUG AT SIDE MEMBER, FOR ELECTROLYTIC IMMERSION-PAINT HOLES | 002 |
| 26 | A 116 987 08 44 | EXPANSION PLUG REAR SIDE MEMBER | 002 |
| 26 | A 124 997 07 86 | PLUG REAR SIDE MEMBER | 002 |
| 29 | A 115 987 04 44 | EXPANSION PLUG REAR SIDE MEMBER | 002 |
| 32 | A 123 987 07 44 | EXPANSION PLUG TRANSVERSE CONTROL ARM TO REAR AXLE | 002 |
| 35 | A 116 987 12 44 | EXPANSION PLUG REAR WHEELHOUSE, INSIDE | 004 |
| 35 | A 116 987 12 44 | EXPANSION PLUG WAX HOLES IN REAR WHEELHOUSES, INSIDE | 002 |
| 44 | A 123 987 04 44 | EXPANSION PLUG AT SIDE MEMBER, FOR ELECTROLYTIC IMMERSION-PAINT HOLES | 004 |
| 47 | A 201 987 01 44 | EXPANSION PLUG STEERING INTERMEDIATE ARM PIVOT BEARING | 001 |
| 50 | A 000 987 18 40 | RUBBER BUFFER MAIN CABLE HARNESS TO RIGHT FRONT WHEELHOUSE | 002 |
| 50 | A 000 987 18 40 | RUBBER BUFFER AUXILIARY HEATER BRACKET TO RIGHT FRONT WHEELHOUSE | 001 |
| 50 | A 000 987 18 40 | RUBBER BUFFER OIL TANK BRACKET TO RIGHT FRONT WHEELHOUSE | 003 |
| 50 | A 000 987 18 40 | RUBBER BUFFER IGNITION COIL BRACKET TO LEFT FRONT WHEELHOUSE | 003 |
| 50 | A 000 987 18 40 | RUBBER BUFFER TEMPOMAT (CRUISE CONTROL) ACTUATOR BRACKET TO LEFT FRONT WHEELHOUSE | 003 |
| 50 | A 000 987 18 40 | RUBBER BUFFER RECORDING ODOMETER (TAXI) BRACKET IN THE RIGHT FRONT OF ENGINE COMPARTMENT | 001 |
| 50 | A 000 987 18 40 | RUBBER BUFFER AIR-CONDITIONING-AUTOMATICS BRACKET | 003 |
| 50 | A 000 987 18 40 | RUBBER BUFFER STEERING INTERMEDIATE ARM PIVOT BEARING | 001 |
| 56 | A 116 997 08 86 | PLUG PAINT RUN-OFF HOLES IN REAR LID | 003 |
| 56 | A 116 997 08 86 | PLUG IN REAR END PILLAR/REAR FENDER EDGES | 004 |
| 65 | A 110 987 00 39 | RUBBER BUFFER Replaced by: A 000 997 33 20 | - |
| 65 | A 000 997 33 20 | EXPANSION PLUG IN FLOOR BELOW REAR SEAT BENCH | 003 |
| 65 | A 000 997 33 20 | EXPANSION PLUG TO PLUG THE MOUNTING HOLE USED FOR GROUND CONNECTION IN CASE OF R.H.D. | 001 |
| 65 | A 000 997 33 20 | EXPANSION PLUG REAR SIDE MEMBER | 004 |
| 65 | A 000 997 33 20 | EXPANSION PLUG SIDE MEMBER, BOTTOM OUTSIDE | 002 |
| 74 | A 123 997 05 81 | GROMMET IN HAT TRAY, FOR THRU-HOLE OF HEATED REAR WINDOW PANE CABLE | 002 |
| 77 | A 107 997 27 81 | GROMMET WATER DRAIN IN SPARE WHEEL WELL | 001 |
| 77 | A 107 997 27 81 | GROMMET IN REAR END FLOOR, LATERAL | 002 |

| | | | |
|----|-----------------|---|-----|
| 80 | A 123 997 29 81 | GROMMET SIDE MEMBER, BOTTOM OUTSIDE | 002 |
| 86 | A 201 683 00 93 | HOSE Replaced by: A 140 639 00 94 | - |
| 86 | A 140 639 00 94 | HOSE TANK FILLER NECK DRAIN PIPE 750 MM | 001 |
| 89 | A 003 988 82 78 | CLIP Replaced by: A 006 988 33 78 | - |
| 89 | A 006 988 33 78 | CLIP | 001 |
| 92 | A 000 995 52 44 | CLAMP | 001 |
| 95 | A 123 683 21 36 | COVERING LEFT,TORSION BAR ASSEMBLY HOLE IN FRONT WHEELHOUSE | 001 |
| 95 | A 123 683 22 36 | COVERING RIGHT,TORSION BAR ASSEMBLY HOLE IN FRONT WHEELHOUSE | 001 |
| 98 | A 001 987 56 46 | SEALING CORD PAINT RUN-OFF HOLE IN REAR WINDOW OPENING  [404] ORDER BY THE METER | NB |