

loosen 2 philips screws to panel  
above passenger footwell. panel  
slides forward (towards firewall)  
then down and out.





looking up towards bottom of dash, you'll find hatch to charcoal filter compartment. slide "H" shaped latch towards passenger seat.





hatch can now be removed. set aside.





insert fingers in recessed area of filter.  
pull straight down towards the floor.





i took a knife to the exposed parts and literally, dug out the old charcoal. be careful not to damage the plastic lattice work.



i was left with a basket shell. I then inserted end of panty hose and began to fill, pack charcoal firmly into the expanding nylon until the plastic carrier was full. tied off and replaced filter into the car.