

Side 1		A Fuse designation		Ⓢ 210 545 15 00		Side 2		A Fuse designation		Ⓢ 210 545 15 00			
function	fuse - no.	function	fuse - no.	function	fuse - no.	function	fuse - no.	function	fuse - no.	function	fuse - no.		
Adjustable mirror, driver's side	16,(3)*	Dome light rear	(3,19)*	Locking check - back	41,(5,19)*	Tail gate closing assist (T-model)	(5,7,19)*	Adjustable mirror, passen. side	(1,3)*	Driver's power window	16,(3)*	Telephone (SE)	23,(15)*
Adjustable steer. column (SE)	(8,9,13,14)*	Elect. Stability Program (SE)	(11)*	Oil cooler (SE)	19	Tilting / sliding roof (SE)	41,(4)*	ADS (SE)	(11)*	Engine fan	20,41	Trailer power supply (SE)	(12)*
Airbag / sidebag control unit	13	Engine residual heat system (SE)	4,7,(5,19)*	Parktronic system (SE)	15	Trunk light	(3,19)*	Airbag fault indicator lamp	10	Fanfare	40,41	Turn signal, t. s. indicator lamp	41
Anti - theft alarm system (SE)	(5,11,19)*	Folding exterior mirror (SE)	14	Passenger side power window	(1,3)*	Washer water heater	42	Autom. comfort seat belt (SE)	12	Fuel pump	(6)*	Windshield washer system	41,43,(5,19)*
Autom. dimming ext. mirror (SE)	(4)*	Fuel pump	(6)*	Power window, rear left	18,(3)*	Wipe system	41,44	Autom. dimming int. mirror (SE)	(4)*	Garage door opener	(4)*	****	****
Autom. seat occupied recognition	13	Garage door opener	(4)*	Power window, rear right	(2,3)*	****	****	Autom. temperature control	4,7	Glove compartment light	3	****	****
Blower motor AC	4,7	Hazard warning flasher	41	Radio (SE)	11,(5)*	Rear head release	41,(5,19)*	Central locking system	16,41,(1,4,5,19)*	Hazard warning flasher	41	Rear plug socket (T-model)	11
Cigar lighter	1 or 6	Headlamp flasher	3,41	Rear window wiper (T-model)	12,41,44,(19)*	Remote trunk release	(3,5,19)*	Convenience locking	16,41,(1,4,19)*	Headlamp range Xenon (SE)	15	Reverse gear recognition	(3)*
Cooler box (SE)	(10)*	Headlamp washer system (SE)	41,45	Seat adjustment (SE)	16,(1,8,9,13,14)*	Seat heater (SE)	12,(17,18)*	Courtesy lights	16,18,(1,2,19)*	Headlamp washer system (SE)	41,45	Sound system (SE)	(16)*
Dome light front	(4)*	Heated mirror, driver's side	16	Heater booster (SE)	17	Steering lock	9	Dome light front	(4)*	Heated mirror, passenger side	(1)*	Sun blind for rear window (SE)	12
		Heated mirror, passenger side	(1)*	Instrument cluster	4,7					Heated rear window	41,(19)*		
		Heater booster (SE)	17							Instrument cluster	4,7		
		Instrument cluster	4,7										

fuse - no.	fuse rating+col.	fuse - no.	fuse rating+col.
2,10,23,42,(3,11,15)*	7,5A --- brown	(4,5,6,8,9,12,13,14,16)*	25 A --- natural
4,12,13,40,43,(10)*	10 A --- red	20, 45	30 A --- green
1,3,6,7,9,11,14,15,19,41	15 A --- blue	44,(19)*	40 A --- orange
16,17,18,(1,2,7,17,18)*	20 A --- yellow		

Please note : Further fuses on side 2 !!!

*Note : Fuses in brackets (thin lettering) are to be found under the rear seat. Further fuses are to be found in the cockpit near the light switch. The fuse extractor is to be found in the vehicle tool kit. (SE) = function of a special equipment item.

Warning: Danger of overloading! Only use specified fuses.

Fuse card 1 - Located in cover of fuse panel in engine bay. Spare fuses stored there.