

1995 Mercedes Benz E Class



There is no exterior photo for this vehicle.


Remote Start, Security, Keyless Entry, Accessories

Item	Wire Color	Polarity	Wire Location
12 Volts	red	+	ignition harness -
Second 12 Volts			
Starter	purple	+	access by pulling
Second Starter			
Ignition	pink/red	+	instrument cluster
Second Ignition	pink/yellow(2nd acc)	+	
Third Ignition			
Accessory	pink/green	+	out of front of dash
Second Accessory			
Third Accessory			
Keysense			
Data Bus			
Can Bus High			
Can Bus Low			
Can Bus Sw			
Power Lock	blue or green	E	either kick panel
Power Unlock	same wire		
Lock Motor			
Driver Unlock Motor			
Passenger Unlock Motor			
Parking Lights (-)			
Parking Lights (+)	gray, gry/wht		lt. switch or alarm
Hazards			
Turn Signal (Left)			
Turn Signal (Right)			
Headlight	white/yellow	+	at light switch
AutoLights			
Reverse Light			
Left Front Door Trigger	brn/gry,brn/gry/blk	-	see notes
Right Front Door Trigger			
Left Rear Door Trigger			
Right Rear Door Trigger			

<i>Remote Start, Security, Keyless Entry, Accessories (Continued)</i>			
Item	Wire Color	Polarity	Wire Location
Dome Supervision			
Trunk/Hatch Pin	black/yellow	-	at trunk lt. or alarm
Rear Glass Pin			
Hood Pin	brown/red	-	at switch or alarm mod
Trunk/Hatch Release			
Trunk Release Motor			
Fuel Door Release			
Power Sliding Door (Left)			
Power Sliding Door (Right)			
Factory Alarm Arm	yel/grn or yel/blu	-	door harness, alarm or
Factory Alarm Disarm	green/yellow	-	door harness, alarm or
Disarm No Unlock			
Trunk Alarm Shunt			
Tachometer	green/yel	AC	back of cluster
Wait to Start			
Neutral Safety			
Clutch Pedal			
Fuel Pump			
Rear Defroster			
Mirror Defroster			
Left Front Heated Seat			
Right Front Heated Seat			
Speed Sense			
Brake Wire	black/red/white	+	brake switch or alarm
Parking Brake			
Horn Trigger	black/yellow/pink	+	st. column harness
Wipers			
Left Front Window (Up/Down)			
Right Front Window (Up/Down)			
Left Rear Window (Up/Down)			
Right Rear Window (Up/Down)			
Sun Roof (Open/Close)			
Sun Roof (Limit/Close)			
Memory Seat 1			
Memory Seat 2			
Memory Seat 3			

Audio

Item	Wire Color	Polarity	Wire Location
Radio 12V			
Radio Ground			
Radio Ignition			
Radio Illumination			
Factory Amp Turn-on			
Power Antenna			
Left Front Speaker (+/-)			
Right Front Speaker (+/-)			
Left Rear Speaker (+/-)			
Right Rear Speaker (+/-)			
Center Channel (+/-)			
Subwoofer (+/-)			
Aux. Audio Input Left (+/-)			
Aux. Audio Input Right (+/-)			
RSE Video (+/-)			
RSE Audio Left (+/-)			
RSE Audio Right (+/-)			
Satellite Radio 12 Volts			
Satellite Radio Ground			
Satellite Radio Ignition			
Satellite Radio Antenna			
Satellite Audio Left (+/-)			
Satellite Audio Right (+/-)			

What Fits

Item	Size	Depth	Location
Headunit			
Left Front Speaker			
Left Front Tweeter			
Right Front Speaker			
Right Front Tweeter			
Left Rear Speaker			
Left Rear Tweeter			
Right Rear Speaker			
Right Rear Tweeter			
Center Channel			
Subwoofer			
Left Front Headrest			
Right Front Headrest			
Left Rear Headrest			
Right Rear Headrest			
Satellite Radio Tuner			

Wiring Photo and Notes: Power Lock



Notes:
 (Also see Note below). Blue wire located in main harness with red/wht and brown wires coming out of drivers door. Passenger side same except trigger wire is green. Pump located under rear seat on passenger side.

Wiring Photo and Notes: Parking Lights (+)



Notes:

Factory alarm located in right side of trunk in convertibles. Sedan and coupe alarm under passenger footboard.


Wiring Photo and Notes: Left Front Door Trigger



Notes:

Front doors are brn/gry (may look like brn/wht) - at right pin or alarm module located under passenger foot board. Rear doors are brn/gry/blk-at pin, dash switch, or alarm. Found brown/gray at drivers door pin on the convertible.

Wiring Photo and Notes: Trunk/Hatch Pin



Notes:

Factory alarm located in right side of trunk in convertibles. Sedan and coupe alarm under passenger footboard.



Wiring Photo and Notes: Hood Pin



Notes:

Factory alarm located in right side of trunk in convertibles. Sedan and coupe alarm under passenger footboard.

Wiring Photo and Notes: Factory Alarm Arm




Notes:

Found under drivers floormat on the convertible. When using ignition-controlled door locks it may be necessary to interrupt the factory alarm arm wire with a relay while the ignition is on. This will keep the ignition lock from arming and setting off the factory alarm while you are driving.




Wiring Photo and Notes: Factory Alarm Disarm



Notes:

Found under drivers floormat on the convertible.



Wiring Photo and Notes: Tachometer



Notes:
3 pin connector; also found left of steering column in main harness.

Wiring Photo and Notes: Brake Wire



Notes:

Factory alarm located in right side of trunk in convertibles. Sedan and coupe alarm under passenger footboard.



© 2015 Directed. All rights reserved.

DirectWire and its vehicle information are for the sole use of authorized Directed personnel and it's participating dealers and distributors. The information contained on these pages may contain confidential and privileged information. Any unauthorized review, use, disclosure or distribution is prohibited.