



Engine compartment

Leakage - Major components

Check for chafe marks, line routing, damaged components 0053
In the event of leakage, determine cause and perform repair via separate work order

Check condition of poly-V-belt 1351

Check catch, safety catch and hinges on engine hood for proper operation 8851

Check the following fluid levels, correct if necessary.

If there is a loss of fluid, determine cause and perform repair with separate work order

Brake system 4210

Power steering 4611

Windshield washer system, incl. rear window washer (where applicable) 8210

Wheels, brakes

Inspect tires for damage and splits, measure tread depth and record in mm 4051

Check thickness of brake pads, front and rear 4253

Correct tire inflation pressure ----