

Code	Designation	Coordinates
A0	Color code key	80L
A7/3	SBC hydraulic unit	40L
B4/1	Left tank half fuel level sensor	47L
B4/2	Right tank half fuel level sensor	46L
E3	Left taillamp	17L 25L
E3e2	Outer left taillamp, parking lamp, rear fog lamp	18L
E3e3	Left backup lamp	16L
E3e4	Left stop lamp	17L 18L
E3e5	Inner left taillamp, rear fog lamp	16L
E3e7	Inner left turn signal lamp	17L 25L
E3e9	Left stop lamp, taillamp and parking lamp	25L
E4	Right taillamp	22L 26L
E4e1	Outer right turn signal lamp	23L 27L
E4e2	Outer right taillamp, parking lamp, rear fog lamp	23L
E4e3	Right backup lamp	20L
E4e4	Right stop lamp	22L
E4e5	Inner right taillamp, rear fog lamp	21L
E4e7	Inner right turn signal lamp	21L
E4e9	Right stop lamp, taillamp and parking lamp	27L
E15/8	Left load compartment lamp	10L
E15/9	Right load compartment lamp	12L
E18/1	Luggage compartment lamp	14L
E19/1	Left license plate lamp	4L
E19/2	Right license plate lamp	6L
E21	Center high-mounted stop lamp	7L 9L
E40	Trunk lid ambient lamp	3L
F33	Rear prefuse box	1L
F33f79	Fuse 79	1K
M3	Fuel pump	49L
M44	Charge air cooler circulation pump	51L
N3/9	CDI control unit	65L 66L
N3/10	ME-SFI [ME] control unit	65L
N10/1	Driver-side SAM control unit with fuse and relay module	62L 62L
N10/2	Rear SAM control unit with fuse and relay module	4A 12A 20A 28A 36A 44A 52A 60A 68A 77A
N10/2f1	Fuse 1	71C
N10/2f2	Fuse 2	73C
N10/2f4	Fuse 4	48C
N10/2f7	Fuse 7	31C
N10/2f11	Fuse 11	28C
N10/2kA	Fuel pump relay	49A
N10/2kB	Relay 2, circuit 15R	27A
N10/2kD	Rear wiper relay	30A

N32/1	Driver front seat adjustment control unit with memory	72L
N32/2	Front passenger front seat adjustment control unit with memory	76L
N111	Rear door control unit	30L
S88/4	Pawl rotary tumbler switch	34L
S88/6	Trunk lid contact switch	38L
S88/8	Trunk lid external operation switch	36L
U57	Valid for station wagon	8E 24E
U58	Valid for sedans and LWB sedans	4E 13E 33E
U71	Valid for seat adjustment with memory	71F
U137	Valid for engine 112 and 113	52F
U285	Valid for partially electric seat adjustment	68F
U292	Valid for all except E 55 AMG	48F
U320	Valid for engine 628	60G 64G
U425	Valid for E 55 AMG	50F
U739	Valid for engine 271	60F
U740	Valid for engine 646	60F
U741	Valid for engine 647	60F
U742	Valid for engine 648	56F
U819	Valid for engine 272	52F
U828	Valid for super low emission	45F 48F
U880	Valid for engine 642	56F
U882	Valid for engine 629	56F
U913	Not valid for super low emission	45F 48F
W2	Ground (right front, at lamp unit)	51G
W6	Ground (left wheelhouse in luggage compartment)	7E 20E 49E
W6/1	Ground (left taillamp in luggage compartment)	26E
X30/7	Left voltage distributor (CAN) connector	43L
X30/9	Circuit 15 voltage distributor	78L
X36/3	Fuel pump wiring harness connector	45H 48H
X62	Rpm sensor connector (signals)	40H
Z6/20	Rear-end door ground connector sleeve	5H 6H 8H 11H 14H 19H 26H 35G