Shift mechanism does not move out of P

You will find a possible remedy in the chapter "DIRECT SE-LECT module". On vehicles with center shifter console and ESM, check whether the shift rod is hooked in/secured properly. On vehicles on which the EHS has been replaced, make sure that the selector valve is correctly mounted in the selection range detent plate.



Correctly engaged selector valve in selection range detent plate