

	Adjust		
1	Set time on instrument cluster		
2	Calibrate power window	i Move respective window to upper stop and hold power window switch depressed for approx. 1 s.	
3.1	Activating steering angle sensor	Vehicles up to model year 04	AR46.10-P-0300-01T
4.1	Normalize panoramic glass roof	On vehicles with code (413) Panoramic glass roof with top sliding roof: / Remove panoramic glass roof fuse from fuse box (refer to assignment diagram in the main fuse box cover). / Reinstall panoramic glass roof fuse. / Switch on ignition. / Move sliding roof lining to front and rear stop and hold sliding roof lining switch depressed for approx. 1 s. / Move panoramic glass roof to front and rear stop and keep roof switch depressed for approx. 1 s.	
4.2	Normalize tilting/sliding roof	On vehicles with code (414) Power glass tilting/sliding roof: / Remove tilting/sliding roof fuse from fuse box (refer to assignment diagram in the main fuse box cover). / Reinstall tilting/sliding roof fuse. / Switch on ignition. / Move tilting/sliding roof to front and rear stop and keep roof switch depressed for approx. 1 s.	