



P54.21-2171-07

## Shown on model 211.0

1 Bolts  
2 Cover

3 Electrical connector

N93 Central gateway control unit

## Modification notes

5.7.06	"Disconnect/connect battery ground line" removed		
--------	--	--	--

	Remove/install		
	Notes on avoiding damage to electronic components due to electrostatic discharge		<a href="#">AH54.00-P-0001-01A</a>
1.1	Store basic data from central gateway control unit (N93) temporarily in STAR DIAGNOSIS	When installing new central gateway control unit (N93).	
	Connect STAR DIAGNOSIS and read out fault memory	<b>i</b> <b>Install:</b> Transfer the temporarily stored basic data to the new central gateway control unit (N93).	<a href="#">AD00.00-P-2000-04TX</a>
		STAR DIAGNOSIS diagnosis system	<a href="#">*WH58.30-Z-1048-13A</a>
2	Remove bolts (1)		
3	Unclip clip from cover (2)		
4	Fold cover (2) down until central gateway control unit (N93) is accessible	.	
5	Disconnect electrical connector (3)		
6	Unclip central gateway control unit (N93) from cover (2) and remove		
7	Install in the reverse order		

## Commercially available tools

Number	Designation	
WH58.30-Z-1048-13A	STAR DIAGNOSIS diagnosis system, Compact Passenger Car	6511 1801 00