

MODEL 211.0



P54.10-2172-07

- | | | |
|---------------------------|------------------|-------------------|
| 1 Nut | 5 Positive cable | 9 Retaining strap |
| 2 Ground cable | 6 Bleed hose | G1 Battery |
| 3 Positive terminal cover | 7 Screw | |
| 4 Nut | 8 Bracket | |

	Remove/Install		
Danger!	Risk of explosion caused by oxyhydrogen gas. Risk of poisoning and caustic burns caused by swallowing battery acid. Risk of injury caused by burns to skin and eyes from battery acid or when handling damaged lead-acid batteries	No fire, sparks, open flames or smoking. Wear acid-resistant gloves, clothing and safety glasses. Pour battery acid only into suitable and appropriately marked containers.	AS54.10-Z-0001-01A
	Notes on battery		AH54.10-P-0001-01A
	Notes on AGM battery		AH54.10-P-0002-01A
1	Disconnect ground line (2) from the battery (G1)		AR54.10-P-0003T
2	Remove positive terminal cover (3)		
3	Loosen nut (4) and remove positive lead (5) from the battery (G1)		*BA54.10-P-1012-01C
4	Pull off vent hose (6)		
5	Unscrew screw (7) and remove bracket (8)		
6	Loosen retaining strap (9) and take battery (G1) with carrying yoke out of the luggage compartment	Installation: Pay attention to correct seating of the battery (G1) in the spare wheel well.	
7	Install in the reverse order		

Battery

Number	Designation	Model 211
BA54.10-P-1012-01C	Nut, battery cable to battery terminal	M6 Nm 7