


## MODEL 211.2 /6

## Left antenna amplifier module

Shown on model 211.2

- 1 Nut  
2 Electrical connectors

A2/64 Left antenna amplifier module



P82.62-2455-05

☒ ☒	Remove/install		
⚠	Notes on avoiding damage to electronic components due to electrostatic discharge		AH54.00-P-0001-01A
1.1	Remove D-pillar paneling on left	Model 211.2	AR68.30-P-4495T
1.2	Remove existing paneling on left D-pillar until the left antenna amplifier module (A2/64) is accessible	Model 211.6	
		<p><b>i</b> Whether paneling exists or what paneling version is used depends on the vehicle equipment.</p>	
2	Unscrew nut (1)		
3	Disconnect electrical connectors (2) and left antenna amplifier module (A2/64)		
4	Install in the reverse order		