AP41.10-P-4152-01ZA Page 1 of 1

|--|

1 Check spacers in vicinity of fitted sleeves (arrows) for cracks (visual inspection).

2 If there is evidence of deformation, relieve stress from propeller shaft. If the deformation

is permanent, the flexible coupling must be replaced as a separate repair order.

If there are cracks or permanent deformations, replace flexible coupling as a separate repair order.

