

Item	Designation	Coordinates
A1	Instrument cluster	4A 12A 20A
A1e1	Left turn signal indicator lamp	13A
A1e2	Right turn signal indicator lamp	14A
A1e3	High beam indicator lamp	11A
A1e4	Fuel reserve indicator lamp	18A
A1e7	Brake fluid and parking brake warning lamp	7A
A1e9	Seat belt warning lamp	19A
A1e15	Airbag indicator and warning lamp	3A
A1e16	Preglow indicator lamp	21A
A1e17	ABS indicator lamp	22A
A1e26	'CHECK ENGINE' MIL	17A
A1e41	ESP and ABS warning lamp	16A
A1e54	Coolant temperature warning lamp	9A
A1e58	Engine diagnosis indicator lamp	7A
A1e59	DTR warning lamp	17A
A1h1	Warning buzzer	8A
A1h2	Audible turn signal indicator	13A
A1p1	Coolant temperature gauge	9A
A1p2	Fuel level and reserve indicator	10A
A1p5	Tachometer	22A
A1p6	Electronic clock	15A
A1p8	Electronic speedometer	10A
A1p12	Gear indicator	6A
A1p13	Multifunction display	5A
A1r1	Instrument illumination brightness control and reset button	2A
N10/1	Driver-side SAM control unit with fuse and relay module	3L

Item	Designation	Coordinates
U74	Valid for diesel engines	2H 20A
U75	Valid for gasoline engines	2H
W15/1	Ground (right footwell)	13L
X30/4	Right voltage distributor (CAN) connector	11L
X30/5	Left voltage distributor (CAN) connector	8L
Z3/11z2	Circuit 15 connector sleeve (fused)	5G
Z6/46z8	Ground (W15/1) connector sleeve	13G
Z7/1	Tml. 30 connector sleeve	2F
Z37/6	CAN databus (high) connector sleeve	7G
Z37/7	CAN bus (low) connector sleeve	8G