

## ADDITIONAL INSTALLATION INFORMATION:

WWW.MR12V.COM/GUIDES-1

## DIP SWITCHES SETTINGS:

### FOR ALL ADAPTERS

	DIP 4
BT Handsfree OFF	ON
BT Handsfree ON	OFF

\*\*\* If factory Bluetooth handsfree is installed, please switch off adapter's BT Handsfree

### FOR AUDI MMI 2G ADAPTERS

	DIP 1	DIP 2	DIP 3
Default Volume	OFF	OFF	OFF
- 2dB	ON	OFF	OFF
- 4dB	OFF	ON	OFF
- 6dB	ON	ON	OFF
+ 1dB	OFF	OFF	ON
+ 2dB	ON	OFF	ON
+ 3dB	OFF	ON	ON
+ 4dB	ON	ON	ON

### FOR AUDI MMI 3G ADAPTERS

	DIP 1
Adapter in work	OFF
Factory CDC in work	ON

\*\*\* Factory CDC and adapter not allowed to work at the same time

### FOR BMW ADAPTERS

Factory Equipped:	DIP 1	DIP 2	DIP 3
CD Only Changer (E6x)	ON	OFF	OFF
CD/MP3 Changer (E6x)	OFF	OFF	ON
CIC Head Unit	OFF	ON	ON
Professional CD (E9x)	OFF	OFF	OFF

### FOR MERCEDES BENZ ADAPTERS

	DIP 1	DIP 2	DIP 3
Default Volume	OFF	OFF	OFF
- 2dB	ON	OFF	OFF
- 4dB	OFF	ON	OFF
- 6dB	ON	ON	OFF
+ 1dB	OFF	OFF	ON
+ 2dB	ON	OFF	ON
+ 3dB	OFF	ON	ON
+ 4dB	ON	ON	ON

### FOR PORSCHE ADAPTERS

Heat Unit Type:	DIP 1	DIP 2	DIP 3
CDR			ON
PCM			OFF
Default Volume	OFF	OFF	
- 2dB	ON	OFF	
- 4dB	OFF	ON	
+ 2dB	ON	ON	

### FOR VOLVO ADAPTERS

Model / Year	Player	DIP 1	DIP 2	DIP 3
XC90 2002 - 2006	6 Disc	ON	OFF	OFF
XC90 2007 - 2012	6 Disc	OFF	OFF	OFF
XC90 2007 - 2012	1 Disc	ON	ON	OFF
S40 2002 - 2005	6 Disc	ON	OFF	OFF
C30/C70/S40/V50 2006 - 2012	6 Disc	OFF	OFF	OFF
C30/C70/S40/V50 2006 - 2012	1 Disc	ON	ON	OFF
S80 / XC70	6 Disc	OFF	OFF	ON
S80 / XC70	1 Disc	OFF	ON	OFF

\*\*\* Power cables must be clamped to battery cable (Non-switchable Constant Power)

### FOR RANGE ROVER ADAPTERS

Model / Year	Player	DIP 1	DIP 2	DIP 3
Free Lander	1 Disc	OFF	ON	OFF
Free Lander	6 Disc	OFF	OFF	ON
Range Rover 2006 - 2009		ON	OFF	ON

\*\*\* Power cables must be clamped to battery cable (Non-switchable Constant Power)