


MODEL 211.0/ 2


Shown on model 211.0

- 1 Inner sealing rail
2 Rear door



P72.12-2202-11

☒ ☒	Remove/Install		
1	Remove door lining on rear door	On vehicles except code (Z04) Light armoring On model 211.065/070 with code (Z04) Light armoring	AR72.12-P-1010T AR72.12-P-1010TG
2	Unclip inner sealing rail (1) from rear door (1) with mounting wedge	☑ i Installation: Inner sealing rail (1) should make complete contact on inner door panel	*110589035900
3	Install in the reverse order		



110 589 03 59 00

Mounting wedge