


MODEL 211.0


except CODE (287) Through-loading feature

except CODE (924) Bivalent natural gas drive

- 1 Center paneling in trunk
- 2 Damping
- 3 Carrier plate cover



P68.30-2506-11

	Remove/Install		
1	Remove trunk floor covering from trunk		
2	Remove left or right paneling in trunk		AR68.30-P-4800T
3	Remove damping (2)		
4	Unscrew screws (arrows) and remove carrier plate cover (3).		
5	Loosen center paneling in trunk (1) and move out of left and right paneling in trunk		
6	Remove center paneling in trunk (1)		
7	Install in the reverse order		