

1 Overpressure reservoir

Strut З

4 Bolts P91.25-2269-07

2 Bracket

XX	Remove/Install		
1	Remove the pneumatic pump for the dynamic seat control		AR91.25-P-1580TX
2	Take out bracket (2)		
3	Remove strut (3)		
4	Remove bolts (4)		
5	Disconnect the pneumatic lines from the overpressure reservoir (1) to the dynamic seats and remove the overpressure reservoir (1)		
6.1	Modify the pneumatic lines to the pneumatic pump for dynamic seat control	Only when installing a new overpressure reservoir (1).	
7	Install in the reverse order		