



P83.40-3069-09

Shown on model 211.0

1	AC housing	M2/7	Right blend air flap actuator	N10/2	Rear SAM control unit with fuse and relay module
A1	Instrument cluster	M2/15	Left and right footwell flaps actuator motor	N10/11	Passenger-side SAM control unit
A9	Refrigerant compressor	M2/16	Left and right defroster flaps actuator motor	N22	AAC [KLA] control and operating unit
A32m1	Blower motor	M2/22	Center outlet flap actuator motor	N69/1	Door control unit front left
A32n1	Blower regulator	M4/7	Engine and AC electric suction fan with integrated control	N69/2	Door control unit front right
B10/4	In-car temperature sensor	M13	Coolant circulation pump	N69/3	Door control unit rear left
B10/6	Evaporator temperature sensor	M16/32	Heat exchanger shutoff motor	N69/4	Door control unit rear right
B12	Refrigerant pressure sensor (as of 1.6.05)	N3/9	CDI control unit (with diesel engine)	N70	Overhead control panel control unit
B12/2	Refrigerant pressure and temperature sensor (up to 31.5.05)	N3/10	ME-SFI [ME] control unit (with gasoline engine)	N70b1	In-car temperature sensor
B14	Outside temperature display temperature sensor	N10/1	Driver-side SAM control unit with fuse and relay module	N73	EIS [EZS] control unit
B31/2	Air humidity sensor (up to 31.8.06)			N93	Central gateway control unit
M2/5	Fresh air/air recirculation flaps actuator motor			R22/3	Heater booster (for engines 271, 628, 646, 647 and 648)
M2/6	Left blend air flap actuator			S17/3	Left front door contact switch
				S17/4	Right front door contact switch
				S17/5	Left rear door contact switch
				S17/6	Right rear door contact switch