

	C-Class	CL-Class	CLS-Class	E-Class	G-Class	GL-Class	GLK-Class	M-Class	R-Class	S-Class	SLK-Class
Tire checks											
Tire rotation (where applicable)	•	•	•	•	•	•	•	•	•	•	•
Inspect tires for damage, measure tread depth	•	•	•	•	•	•	•	•	•	•	•
Check TIREFIT sealant expiration date (where applicable)	•	•	•	•	•	•	•	•	•	•	•
Activate Tire Pressure Monitoring System	•	•	•	•	•	•	•	•	•	•	•
Chassis checks											
Visually check brake system components, lines, hoses, calipers	•	•	•	•	•	•	•	•	•	•	•
Check thickness of brake pads and disks, front and rear wheels removed	•	•	•	•	•	•	•	•	•	•	•
Chassis and load-bearing body components: Check for damage and corrosion	•	•	•	•	•	•	•	•	•	•	•

Service at 30,000 miles or 3 years

Required Service Work

	C-Class	CL-Class	CLS-Class	E-Class	G-Class	GL-Class	GLK-Class	M-Class	R-Class	S-Class	SLK-Class
Engine – oil and filter change	•	•	•	•	•	•	•	•	•	•	•
Check catch, safety catch and hinges on engine hood for proper operation	•	•	•	•	•	•	•	•	•	•	•
Clean visible area of water deflector	•	•	•	•	•	•	•	•	•	•	•
Check water drain in air/water duct for obstructions; clean if soiled	•	•	•	•	•	•	•	•	•	•	•
Fill up DEF (engine 642)	•	•	•	•	•	•	•	•	•	•	•



WARNING

Please make sure you read the technical documentation, such as the Operator's Manual and workshop information, before carrying out any maintenance work.

Maintenance Booklet

	C-Class	CL-Class	CLS-Class	E-Class	G-Class	GL-Class	GLK-Class	M-Class	R-Class	S-Class	SLK-Class
Reset maintenance service indicator in instrument cluster	•	•	•	•	•	•	•	•	•	•	•
Replace dust filter								•			
Check thickness of brake pads, front and rear	•	•	•	•	•	•	•	•	•	•	•
Correct tire inflation pressure	•	•	•	•	•	•	•	•	•	•	•
Correct inflation pressure in spare tire (where applicable)	•	•	•	•	•	•	•	•	•	•	•
Replace coolant for main circuit (engine 275)		•								•	
Check the following fluid levels; correct if necessary											
If there is a loss of fluid, determine cause and perform repair with separate work order											
Check coolant level	•	•	•	•	•	•	•	•	•	•	•
Brake system	•	•	•	•	•	•	•	•	•	•	•
Power steering	•	•		•	•	•	•		•	•	•
Windshield washer system	•	•	•	•	•	•	•	•	•	•	•
Active Body Control (ABC) (if applicable)		•								•	
Differential lock mechanism fluid reservoir					•						

Recommended Service Work

	C-Class	CL-Class	CLS-Class	E-Class	G-Class	GL-Class	GLK-Class	M-Class	R-Class	S-Class	SLK-Class
Replace wiper blades	•	•	•	•	•	•	•	•	•	•	•
Replace combination filter	•	•	•	•	•	•	•	•	•	•	•



WARNING

Please make sure you read the technical documentation, such as the Operator's Manual and workshop information, before carrying out any maintenance work.

	C-Class	CL-Class	CLS-Class	E-Class	G-Class	GL-Class	GLK-Class	M-Class	R-Class	S-Class	SLK-Class
Electrical system checks											
Horn, high beam flasher, hazard warning lamps, turn signals	•	•	•	•	•	•	•	•	•	•	•
Warning/indicator lamps, illumination and interior lighting/exterior lighting	•	•	•	•	•	•	•	•	•	•	•
Check trunk/cargo compartment lighting	•	•	•	•	•	•	•	•	•	•	•
Check condition of battery (main/starter/auxiliary) using "Midtronics EXP 717" tester	•	•	•	•	•	•	•	•	•	•	•
Visual and functional checks											
Check windshield washer and headlamp cleaning system	•	•	•	•	•	•	•	•	•	•	•
Clean and lubricate soft top seals					•						
Night View Assist Plus camera – clean windshield behind the camera cover (where applicable)				•						•	
Tire checks											
Tire rotation (where applicable)	•	•	•	•	•	•	•	•	•	•	•
Inspect tires for damage, measure tread depth	•	•	•	•	•	•	•	•	•	•	•
Check TIREFIT sealant expiration date (where applicable)	•	•	•	•	•	•	•	•	•	•	•
Activate Tire Pressure Monitoring System	•	•	•	•	•	•	•	•	•	•	•
Chassis checks											
Visually check brake system components, lines, hoses, calipers	•	•	•	•	•	•	•	•	•	•	•
Check thickness of brake pads and disks, front and rear wheels removed	•	•	•	•	•	•	•	•	•	•	•

 **WARNING**

Please make sure you read the technical documentation, such as the Operator's Manual and workshop information, before carrying out any maintenance work.