


P68.30-3417-09

- | | | |
|----------------------------------|--|---|
| 1 Headliner | 14 Edge guard | E14/2 Right sun visor mirror lamp |
| 2 Cable duct | 15 Frame | E15/3 Rear dome lamp |
| 3 Headliner cover | 16 Cover | N70 Overhead control panel control unit (with code (414) Power glass tilting/sliding sunroof) |
| 4 C-pillar paneling | A44/3 Rear PARKTRONIC warning indicator (with code (220) PARKTRONIC or with code (230) Exclusive parking assist) | N70/3 Overhead control panel electronics (without code (414) Power glass tilting/sliding sunroof) |
| 5 Clips | A67 Inside rearview mirror | X42/28 Electrical connector for interior protection (with code (882) Interior monitoring (with ATA only)) |
| 6 Hook | B38/2 Rain/light sensor | |
| 7 Clip | E14/1 Left sun visor mirror lamp | |
| 8 Inside rearview mirror bracket | | |
| 9 Electric wiring harnesses | | |
| 10 Electrical connector | | |
| 11 Grab handle | | |
| 12 Sun visor | | |
| 13 A-pillar cover | | |



P68.30-3418-08

Shown with CODE (413) Panorama sliding roof

- | | | |
|-------------|--|-------------------|
| 1 Headliner | 17 Velcro strip | 19 Passenger seat |
| 6 Hook | 18 Wiring harness for headliner and sliding roof | |



Remove/install

1.1	Open panoramic sliding roof	On vehicles with code (413) Panoramic sliding roof	
1.2	Open tilting/sliding roof	On vehicles with code (414) Power glass tilting/sliding roof	
2	Remove right rear door sill molding		AR68.30-P-4100EW
3	Completely remove edge guard (14) on door cutout of right rear door		
4.1	Remove rear seat backrest	On vehicles with code (882) Interior monitoring (with ATA only) and without code (287) Through-loading feature or without code (224) Design individual rear seat system	AR91.12-P-1620CW
4.2	Remove rear seat backrest	On vehicles with code (882) Interior monitoring (with ATA only) and with code (224) Design individual rear seat system	AR91.12-P-1620EW
4.3	Remove side upholstery	On vehicles with code (882) Interior monitoring (with ATA only) and with code (287) Through-loading feature	AR91.12-P-1710CW
5	Detach bottom paneling on left B-pillar so that top paneling can be removed		
6	Remove top paneling from left B-pillar	i Lay top paneling down to side with belt end fitting attached.	
7	Remove bottom paneling and top paneling from right B-pillar	i Lay top paneling down to side with belt end fitting attached.	
8	Remove left and right C-pillar paneling (4)	i Lay C-pillar paneling (4) down to side with belt end fitting attached.	AR68.30-P-4490EW
9	Detach remaining edge guards (14) in area of headliner (1)		
10	Open cable duct (2), disconnect electrical connector on interior protection (X42/28) and expose wiring harness on headliner and sliding roof (18) from cable duct (2)	On vehicles with code (882) Interior monitoring (with ATA only)	
11	Unclip headliner cover (3) and remove	i On vehicles with code (220) PARKTRONIC or with code (230) Exclusive parking assist, disconnect electrical connector on rear PARKTRONIC warning indicator (A44/3).	
12	Remove rear dome lamp (E15/3)	Only when replacing headliner (1).	
13	Unclip clips (5) from headliner (1)		
14	Remove roller sun blind (12) from counterbearing		
15	Remove overhead control panel control unit (N70) or overhead control panel electronics (N70/3)	i Depending on vehicle equipment.	AR82.20-P-1000CW
16	Remove left sun visor mirror lamp (E14/1) and right sun visor mirror lamp (E14/2)	Only when replacing headliner (1).	
17	Remove inside rearview mirror (A67)		
18	Unclip and remove cover (16)		
19	Disconnect electrical connector (10) from rain/light sensor (B38/2)		
20	Remove inside rearview mirror bracket (8)		
21	Remove clip (7)		
22	Remove grab handles (11) on roof		
23	Move driver and passenger seat (19) toward rear and position backrest downward so that largest possible gap (arrows) is present between passenger seat and B-pillar	w On vehicles with code (864) Rear entertainment system, when folding down backrest, ensure that the left rear display and right rear display are not damaged This clearance (arrows) is required to remove the headliner (1) from the vehicle through the right rear door cutout.	
24	Detach headliner (1) on Velcro strips (17) from roof paneling		
25	Unhook headliner (1) from frame (15) of sliding roof and panoramic roof	On vehicles with code (413) Panorama sliding roof or code (414) Power glass tilting/sliding roof	
26	Slide headliner (1) toward rear until hooks (6) disengage from mounts on roof paneling. Then lay headliner (1) down on seats	i Installation: Position headliner (1) below A-pillar panelings (13) when moving forward. Position headliner (1) above electrical wiring harnesses (9)	
27	Arch headliner (1) at front and rear with aid of helper, then align headliner in vehicle so that headliner (1) can be moved out of rear door cutout toward rear.	w Do not arch headliner (1) excessively, otherwise headliner (1) can be damaged.	
28	Guide headliner (1) through gap (arrows) toward rear out of right rear door cutout. Always keep headliner (1) arched.	w When moving out headliner (1), ensure that the edge areas of the headliner (1) are not kinked or graze against the adjacent components. Otherwise the headliner (1) can be damaged.	

